







7 REMOTE jack

Momentary switches



There are two types of momentary switches: the  type and the  type.


Please use the  type for the foot switch.

Commutateurs à action




Il existe deux types de commutateurs à action momentanée : le type  et le type . Veuillez utiliser une pédale de type .

Interruttore a pedale per il controllo




Esistono due tipi di interruttore a pedale per il controllo: il tipo  e il tipo .

Vi preghiamo di utilizzare il tipo .



モーメンタリースイッチ


モーメンタリースイッチには  と  の 2 種類のタイプがあります。
 タイプのスイッチをお使いください。

Momentschaltern

Es gibt zwei Typen von Momentschaltern: den Typ  und den Typ .
Bitte verwenden Sie den Typ  für den Fußschalter.

Interruptores momentáneos

Hay dos tipos de interruptores momentáneos: el tipo  y el tipo .

Utilice el tipo  para el interruptor de pie.